



1. INSTALL SUPPLIED 1/4-20 BOLT, WASHERS AND NUT THROUGH HOLE AT EACH END OF FIXTURE.
2. INSTALL CABLE GRIPPER ONTO EXPOSED 1/4-20 STUD AT EACH END OF FIXTURE
3. HANG FIXTURE
 - INSTALL A/C CABLE IN MOUNTING LOCATIONS ACCORDING TO INSTRUCTIONS SUPPLIED WITH MOUNTING KIT
 - LIFT FIXTURE INTO POSITION AND FEED A/C CABLE THROUGH CABLE GRIPPER.
 - LEVEL FIXTURE AND TIGHTEN SAFETY NUT AT TOP OF GRIPPER

IMPORTANT: THE NATIONAL ELECTRIC CODE REQUIRES THAT ANY FIXTURE IN EXCESS OF 50 POUNDS MUST BE INDEPENDENTLY SUPPORTED OF THE OUTLET BOX. DAY-O-LITE IS NOT RESPONSIBLE FOR INADEQUATE REINFORCEMENT OF STRUCTURAL SUPPORT SYSTEMS. BE SURE TO UNDERSTAND ALL PROCEDURES PRIOR TO INSTALLATION. ROW CONFIGURATIONS ARE JOB SPECIFIC, CONSULT SHOP DRAWINGS BEFORE CONSTRUCTING ROWS. DAY-O-LITE RESERVES THE RIGHT TO MAKE ANY MECHANICAL OR MATERIAL CHANGES TO THE FIXTURES WHICH DO NOT AFFECT THE APPEARANCE OR PERFORMANCE. THIS PRINT IS THE PROPERTY OF DAY-O-LITE AND THE INFORMATION IT CONTAINS MAY NOT BE USED WITHOUT WRITTEN CONSENT OF DAY-O-LITE.

MODEL NO.:
PRFL-XX-ACT-FILLER----

CONTACT INFORMATION:
126 Chestnut Street, Warwick, RI 02888
Tel. (401) 467-8232 | Fax. (401) 941-2960
E-mail: sales@dayolite.com
WWW: http://www.dayolite.com

PART NUMBER:
970028A0

PAGE:
SHEET 1 OF 1

ISSUED ON:
10/22/19

