## ADL-RO6 DI AC INSTRUCTIONS



BEFORE INSTALLATION OR RISK OF ELECTRICAL SHOCK.













INSTALLED FEED CORD CABLE GRIPPER AND



- DRAWINGS FOR JOB SPECIFIC WIRING FEED TO MAINS POWER, TYPICAL WIRING DIAGRAM SHOWN. REFER TO JOB FIXTURE. CONNECT AC CABLES TO STRUCTURAL CEILING. CONNECT POWER MOUNTING HANGER. INSTALL MOUNTING HANGER TO HOUSING. HANG 1. REMOVE LENS AND TRAY. INSTALL FEED CORD AND CABLE GRIPPER INTO
- SAFETY CAP 2. FIXTURE HEIGHT CAN BE ADJUSTED USING THE CABLE GRIPERS. LOOSEN TOP SAFETY CAP OF GRIPPER, ADJUST CABLE LENGTH AND TIGHTEN TOP
- 3. REINSTALL LOWER TRAY
- REINSTALL LENS



WITH SIMILAIR INSTALLATION. BE SURE TO UNDERSTAND ALL PROCEDURES PRIOR TO INSTALLATION. IMPORTANT: THE NATIONAL ELECTRIC NOT RESPONSIBLE FOR INADEQUATE REINFORCEMENT OF STRUCTURAL SUPPORT SYSTEMS. DAY-O-LITE RESERVES THE RIGHT TO MAKE CODE REQUIRES THAT ANY FIXTURE IN EXCESS OF 50 POUNDS MUST BE INDEPENDENTLY SUPPORTED OF THE OUTLET BOX. DAY O LITE IS SPECIFIC, CONSULT SHOP DRAWINGS BEFORE CONSTRUCTING ROWS. STANDARD OPTIONS/SIZES SHOWN, OTHER OPTIONS AVAILABLE MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN. DISCONNECT POWER DURING INSTALLATION/SERVICING. ROW CONFIGURATION IS JOB THE PROPERTY OF DAY-O-LITE AND THE INFORMATION IT CONTAINS MAY NOT BE USED WITHOUT WRITTEN CONSENT OF DAY-O-LITE. ANY MECHANICAL OR MATERIAL CHANGES TO THE FIXTURES WHICH DO NOT AFFECT THE APPEARANCE OR PERFORMANCE. THIS PRINT IS

CONTACT INFORMATION: WWW http://www.dayolite.com E-mail: sales@dayolite.com Tel. (401) 467-8232 Fax. (401) 941-2960 126 Chestnut Street, Warwick, RI 02888

Lighting Without Limits